

## Envivo Action Camera P1146

### Adjusting time and date of the internal clock

The EnVivo Action Camera has an internal clock with calendar, which works as long as the battery has enough charge. If the camera is started for the first time, it will show a random time, most likely somewhere in 2008. This date is kept as avi-file date with each recording. So it is wise to adjust the internal clock in order to get these dates consistent.

Please proceed as follows :

1. On the PC, make a textfile with Notepad (see Accessories) similar to this example :



Take a time which is some minutes ahead in time, and save it on the harddisk of your PC, and choose

**Tag.txt**

as name.

2. Connect the Envivo Action Camera by means of the USB cable with the PC. Copy this tag.txt file in the root directory of the Action Camera. This is where the directory **DCIM** resides.
3. Take a small pin (a tooth pick e.g.) and reset the Action Camera exactly at the point in time which was written in the tag.txt file.

Ready.

You will see that, after the reset, the tag.txt file was deleted in the camera, but you still have a copy on your harddisk ! From now on, your recordings will have the correct date and time.